FIT IN-EAR BLUETOOTH® HEADPHONES

Antes de comenzar a usar el producto es importante que leas esta guía.

Esta guía aplica a los modelos PC-116349 PC-116387

Montaje



Vista

1) Auricular
2) Botón **Multifunción**
3) Conector de carga
4) LED indicador
5) Micrófono
6) Volumen - / Siguiente
7) Volumen + / Anterior
8) Cable ajustable



Carga de la batería

1.- Conecta el cable cargador al conector de carga (debes levantar la cubierta plástica) y a un cargador USB.
2.- La carga de la batería toma 2 horas.
3.- El LED indicador prendera rojo durante la carga y se apagara al terminar esta.

Nota: Cuando la batería este baja, el LED indicador prendera en rojo cada 15 segundos

Advertencia: Antes de usar la primera vez, carga el dispositivo al menos 2 horas o más para asegurar que la batería está completamente cargada.

Sincronización

1. Presiona y mantén presionado el botón “Multifunción” alrededor de 10-12 segundos hasta que el LED parpadee azul y rojo alternadamente.
2. Enciende la función Bluetooth de tu dispositivo y activa la búsqueda de dispositivos.
3. Una vez que encuentres el dispositivo, lo encontraras como “PC-116349 Headphones” o “PC-116387 Headphones”,, selecciónalo y conéctalo (En caso de que tu dispositivo te solicite un código introduce “0000”).
4. Los audífonos estarán listos para utilizarse.

Encendido / Apagado

Encender: Presiona y mantén presionado el botón “Multifunción” por alrededor de 4 segundos hasta que el LED indicador prenda en azul.
Apagar: Presiona y mantén presionado el botón “Multifunción” por alrededor de 4 segundos hasta que el LED indicador prenda en rojo.

Nota: Una vez que este encendido, el LED indicador prendera azul cada 10 segundos.
Si la conexión se pierde, los audífonos se apagaran automáticamente después de 30 minutos.

Funciones principales

Manos Libres

Botón	Función
Multifunción	**Contestar llamada:** Presiona el botón para contestar una llamada entrante. **Terminar llamada:** Durante una llamada presiona para terminar. **Rechazar una llamada:** Presiona y mantén por 3 segundos. **Cambiar entre Audífonos y dispositivo:** Durante una llamada presiona y mantén por 2 segundos para cambiar entre los audífonos y tu dispositivo o viceversa.
Volumen - / Siguiente	Presiona brevemente para disminuir el volumen
Volumen + / Anterior	Presiona brevemente para aumentar el volumen

Reproducción de Música

Botón	Función
Volumen - / Siguiente	Presiona brevemente para disminuir el volumen Presiona y mantén para reproducir la pista siguiente
Volumen + / Anterior	Presiona brevemente para aumentar el volumen Presiona y mantén para reproducir la pista anterior
Multifunción	Presiona para comenzar la recomenzar la reproducción Presiona nuevamente para continuar la reproducción

Nota: Algunas funciones dependen de las características del dispositivo sincronizado

Cuidados y Precauciones

Para disfrutar tu equipo durante mucho tiempo, te recomendamos:

- No abras por ningún motivo la unidad esto puede causarte un daño e invalidar la garantía.
- Para limpiar utiliza un trapo ligeramente húmedo

Especificaciones técnicas

* Alimentación: ..... 5 Vcc
* Conector: .....micro USB
* Alcance: .....10 m
* Versión Bluetooth®: .....V2.1 + EDR
* Perfiles soportados: ..... A2DP, AVRCP

Audífonos:
* Diámetro del cono: .....10 mm
* Rango de respuesta:..... 20 – 20 000 Hz
* Impedancia:..... 16 ohms
* Sensibilidad: .....102 dB

Micrófono:
* Rango de respuesta: .....50- 16 000 Hz
* Impedancia:..... 2.2 Kohms
* Sensibilidad:.....-42 dB
* Directividad:..... Omnidireccioal

Bateria:
* Tipo: .....Polímero de Litio
* Duracion en llamada: .....6 horas
* Duracion en musica: ,,,

FIT IN-EAR BLUETOOTH® HEADPHONES

USER GUIDE
Read this user guide carefully before using the device.

This guide apply to PC-116349 PC-116387 models

Mounting



View

1) Earcup
2) **Multifunction button**
3) Charge connector
4) LED indicator
5) Microphone
6) Volume - / Next
7) Volume + / Back
8) Ajustable cable



Nota: Cuando la batería este baja, el LED indicador prendera en rojo cada 15 segundos

Charge

Before use the handsfree it is important to charge the battery. Use the micro USB cable to charge, connect one side to charge connector (you need to remove plastic cover) and other side to an USB port or to an USB charger. Charge time will be 2 hours. LED will indicate red during charging and go off when charge is complete.

Note: When the battery power is low, the LED flashes red evary 15 seconds.

Paring

To pair the handsfree follow these steps:

1. Press and hold the “multi-function button” for about 10-12 seconds until LED blinks blue and red alternately.
2.-Activate the Bluetooth function in your device and search the handsfree you will see as “PC-116349” or “PC-116387”
3.-Sellect connect in your device,(In some devices you will need an pin code this is “0000”)

Turn On / Off

Turn On: From OFF. Press and hold the "MFB" button for around 4 seconds until the indicator LED shows blue.
Turn Off: From ON, press and hold the "MFB" button for around 4 seconds until the indicator LED shows red.

Note: Once the unit is on. the LED indicator will flash blue every 10 seconds. When losing connection, the speakerphone will automatically switch itself off in 30 minutes.

5. Working with mobile phone (Tutorial online)
It is important to pair the headset with your Bluetooth mobile phone for the first time use.
5.1 Pairing procedure:
1) . Ensure the headset is off.
2) . Press and hold the MFB button (about 7 seconds) until LED blinks blue and red alternately.
3) . Search the headset from your phone.
4) . Once "Avantree Sacoo." found In search list, follow the steps and enter pin code

Principal functions

Handsfree

Button	Function
Multifunction	**Answering the first call**: Press the "MFB" button once to answer the first call. **Ending a call:** Press the "MFB" button once to end a call. **Reject a call:** Press and hold the 'MFB" button for 3 seconds to reject a call. **Switching a call between headset and mobile phone:** During a call, press and hold "MFB" for 2 seconds to transfer the call to your mobile phone. During a call, press and hold "MFB" for 2 seconds to transfer the call to your headset.
Volume - / Next	Briefly press "V-" to decrease the volume
Volume + /Back	Briefly press *V+" to Increase the volume

Play Music

Button	Function
Volume - / Next	Briefly press "V-" to decrease the volume Previous track: Press and hold "V+" Button
Volume + / Back	Briefly press *V+" to Increase the volume Next track: Press and hold “V-” Button
Multifunction	Play music : Press "MFB" Button Pause : Press "MFB" Button

Nota: Some functions depends of paring device

Cares

• Do not store it at high temperatures (over 45 ° c) such as in a car.
• To clean, get a wet cloth.
• Do not throw it or crush.
• Keep it away from dust.

Technical specifications

* Power supply: ..... 5 Vdc
* Connector: .....micro USB
* Working range: .....10 m
* Bluetooth® version: .....3.0 + EDR
* Supported profiles: ..... A2DP, AVRCP

Headphones:
* Speaker diameter: .....10 mm
* Response range:..... 20 – 20 000 Hz
* Impedance:..... 16 ohms
* Sensibility: .....102 dB

Microphone:
* Response range: .....50- 16 000 Hz
* Impedance:..... 2.2 Kohms
* Sensibility:.....-42 dB
* Directivity:..... Omnidireccioal

Battery:
* Tipe: .....Lithium polymer
* Battery duration: Call: .....6 hours
  Music player: ....6 hours
  Stand by: .....120 hours

*Talk and standby times may vary when used with different devices

Technical specifications are subject to change without prior notice

If you have any question or doubts please do not hesitate to contact us:

Technical support

MEXICO

MX, GDL y MTY 4777 0853
Rest of the country 01800 148 1828

soporte@perfectchoice.me

REST OF THE WORLD

+52 33 3283 1500
+1 855 7373 246

support@perfectchoice.me